### INTRODUCTION

This Application Note shows how Comfort can be interfaced to Dynalite products via Comfort's UCM/Universal.

### Equipment

- 1 Comfort CP9000 Firmware Version 6.023 and above
- 2 UCM/Universal (firmware 6.025 or higher) + AUX485. The AUX485 provides an isolated RS485 interface to the DyNet Bus

### **Reference Manual**

Please refer to the Universal UCM Manual which can be downloaded from <a href="http://www.cytech.biz/universal\_ucm\_manual.html">http://www.cytech.biz/universal\_ucm\_manual.html</a> for detailed instructions on UCM/Universal.

## Connections



### UCM/Universal + AUX485 submodule

Before connecting, set the ID on SW7 to the ID of the UCM according to the table below and according to the number of other UCMs in the Comfort Network. If there is only 1, set the ID to 2. By convention, ID 1 is reserved for the UCM (Ethernet or USB) to write and read from Comfort. Communications Failure alarm is not reported when the UCM with ID=1 is removed from the system. Up to 8 UCMs of different types (e.g. C-Bus, KNX) can be connected to the Comfort network.

ID	SW7-A	SW7-B	SW7-C	SW7-D
1	Short	Short	Short	Short
2	Open	Short	Short	Short
3	Short	Open	Short	Short
4	Open	Open	Short	Short
5	Short	Short	Open	Short
6	Open	Short	Open	Short
7	Short	Open	Open	Short
8	Open	Open	Open	Short

2 The UCM is connected to Comfort via the supplied 4-way white cable from 4-pins header JP2/2A to Comfort's header J7 ("RS485"). It is not necessary to switch off the power to Comfort before plugging in this connection.

- 3 The Green RDY LED on the UCM (D1) should light up and remain on.
- 4 The LEDs D9 (red) and D10 (green) should blink rapidly showing that RS485 communications has been established between Comfort and the UCM. D9 (green) flashing shows that it is receiving communications from Comfort (poll). D10 (red) comes on when the UCM responds to a poll from Comfort.
- 5 Connect the AUX485 KA/KB (JP1) to any Dynalite module's D+/Drespectively; connect the AUX485 V+/V- (JP2) to any Dynalite module's +12V/GND respectively. AUX485 provides isolation between Dynalite Dynet RS485 bus and Comfort
- 6 When sending commands to Dynalite, D12 (red) should blink. This shows that a message has been sent.

## **COMFIGURATOR Programming**

Use Comfigurator 3.5.6 or above.

File	Edit	View	Transfer	Options	Tools	Help					
) 🖻		8 🖪	X	0 0	0		)   <del>*</del>			<sup>₩</sup> Ţ   ⊐x	2
Comfor	t Mo	dules		s							
	Con	troller ('s	ld Na	ame   Typ	e	Version		 Ξ	UCM P	ropertie	es
	1	Ü	Scan For All I	Modules					ld	1	
		U	Scap For LICI	Me					Name	UCMO	1
÷	Кеур	56		.13					Туре	Gener	al
	Doo	rS	Add UCM						Version	6.012	
···· []	Slav SCS	e 8	Write Module	es & Settings	to Com	fort					

In Modules Tab, right click and select Scan for UCMs or Scan for All Modules. The result of the scan should be 2 UCMs, UCM #1 which is the programming UCM and UCM #2 which is the Universal UCM (assuming Universal UCM is ID #2).

File Edit View Transfer	Options Tools Help	
🗅 💕 🚽 🎒 💁 🕹 🖒	। ७ ९ । 🕝 । 🛇 🔍 । 🗯 । 🛒 🕕 📑	u   🔜 💩   🏣 📖   🎛 🎹 💡
Comfort Modules	UCM's	
Controller UCM's UCM01 UCM02 UCM02	Id         Name         Type         Version           1         UCM01         General         6.023           2         UCM02         Universal         6.023	UCM Properties       Id     1       Name     UCM01       Type     General
DoorStations Slaves SCS & RIO's		Version 6.023

Select UCM02 on the left pane to show the Universal UCM properties.

	Jcm02					
	🔿 Write To EEPROM 🛛 💽 Read From EEPR	OM   Reset   Get Status   Save Tem				
Ucm02	Device To Comfort	Alarm To Device Commands To Device				
evpads	UCM/Universal Properties					
orStations	UCM Command Type	Dynalite485				
es 📗	Baud Rate	9600				
RIO's	Parity	None				
	Data Bita	8				
	Data Type	Hex				
	Header Bytes	0				
	Terminator Present	No				
	End of Message Gap (3.3 ms units)	4				
	Checksum Type	Twos Complement				
	Checksum Includes Header	No				
	Parsing Method	Data Position				
	Counter Data Byte/Field Offset	5				
	Counter Ignore Data Byte/Field Offset 1	4				
	Counter Ignore Data Byte/Field Offset 2	6				
	Counter Ignore Data Byte/Field Offset 3	8				
	Counter Ignore Data Byte/Field Offset 4	0				
	Sensor Data Byte/Field Offset	1				
	Sensor Ignore Data Byte/Field Offset 1	0				
	Sensor Ignore Data Byte/Field Offset 2	0				
	Sensor Ignore Data Byte/Field Offset 3	0				
	Sensor Ignore Data Dyte/Field Offset 4	0				
	Keypad Data Byte/Field Offset	5				
	Keypad Ignore Data Byte/Field Offset 1	8				
	Keypad Ignore Data Byte/Field Offset 2	0				
	Keypad Ignore Data Byte/Field Offset 3	0				
	Keypad Ignore Data Byte/Field Offset 4	0				
	Other Types Ignore Data Byte/Field Offset 1	0				

This is the bute /field position (starting with 1) of the bute or field that contains the Sensor val

In UCM/Universal Properties, select the following:

- UCM Command Type as: Dynalite485 •
- End of Message Gap (3.3. ms unit): 4 •
- Checksum Type: Twos Complement ٠
- Counter Data Byte/Field Offset: 5
- Counter Ignore Data Byte/Field Offset 1: 4
- Counter Ignore Data Byte/Field Offset 2: 6
- Counter Ignore Data Byte/Field Offset 3: 8
- Keypad Data Byte/Field Offset: 5 •
- Keypad Ignore Data Byte/Field Offset 1: 8 ٠

Leave other parameters to the default, as they are not important.

## **Device to Comfort**

The Device to Comfort table allows received Dynalite messages to send commands to Comfort, like activating responses (e.g. Turning on air-conditioner), or security commands like arm, bypass, and panic.

Ucm02									
🖻 Write To EEPROM 🛛 🕘 Read From EEPROM 🛛 Reset 🚽 Get Status 🚽 Save Template 🚽 Load Template									
UCM/Univers	sal Properties De	vice To Comfort	Alarm To Dev	vice Commands To	Device Monitor Mode				
🕜 Add Co	ommand 🛛 🤤 D	elete Comman	d Learn				Device	To Comfort	
T	Country Name	Course North	7 N	Deserve News			Туре	ArmNight	
туре	Counter Name	Sensor Name	Zone Name	Response Name	wessage		Message	1C01E681FF64FF1A	
Response					1C01F381FF64FF0D	~~~~			
ArmNight					1C01E681FF64FF1A	~~~~			
KeypadKey						~~~~~			
Counter	Counter001					~			

The Channel Level of the DyNet Linear Channel/Area Control messages can be mapped to Comfort's Counter so that different level can be programmed to trigger different things in Comfort.

The DyNet Key Press / Key Release messages can also be mapped to KeypadKey to simulate a Comfort keypad. The button number in the Dynalite Key Press / Key Release command is associated to the keypad key according to the table below:

Keypad Key	Button Number	Keypad Key	Button Number
0 - 9	0 - 9	Function 0	32
F	10	Function 1	33
*	11	Function 2	34
		Function 3	35
Away (soft)	13	Function 4	36
Night (soft)	14	Function 5	37
Day (Soft)	15	Function 6	38
Panic	16	Function 7	39
Fire	17	Function 8	40
Away (hard)	18	Function 9	41
Night (hard)	19	Function 10 (F)	42
Day (hard)	20	Function 11 (*)	43
Vacation (hard)	21	Function 12 (#)	44
Enter (#)	26	Function 13 (Away)	45
End	27	Function 14 (Night)	46
		Function 15 (Day)	47

Away, Night, Day (soft) - These the keys corresponding to the 3 top left keys on the Comfort keypad. They are "soft" because these keys can be programmed by Comfigurator to other functions and not necessarily for arming to Away, Night and Day.

Away, Night, Day, Vacation (hard) - these keys always arm the system to the respective modes and do not depend on how the function keys are programmed.

Panic, Fire - These are "hard" keys which activate a Panic and Fire alarm respectively on Comfort.

Function 0 to Function 15 - These activate the programmed function keys 0 to 15 on the Comfort keypad using 1 key only so facilitate the use on a Dynalite button or touchscreen.

Enter (#) - This key is like the # key which terminates the entry of the user code to disarm the system. Entering the code and  $\langle ENTER \rangle$  key will disarm the system without entering voice menu. The Enter key should be used on Dynalite (instead of the # key No 12) because there is no speaker on the Dynalite bus which can let the user hear the voice menu.

F and End - The F key corresponds to the bottom right key on the Comfort keypad which together with a number key activates a programmed function.

The F key will also end any voice menu which is playing on the keypad being used or on other keypads. The <END> key will end the voice menu on the keypad but it does not activate a function key with the next number.

The 'Learn' mode is a convenient way to receive Dynalite messages as you can press a button on the Dynalite device and capture the message, and then assign it to one of the function type.

Alternatively, the 'Add Command' can be used to manually enter the Dynalite messages.

# Alarm to Device

Ucm02							
📄 Write To EEPROM	🛛 💽 Read From	m EEPROM	Reset	Get S	tatus	Save Tem	plate   Load Template
UCM/Universal Properti	es Device To Co	omfort Alarm	To Device	Co	mmano	ls To Device	Monitor Mode
Event Type	Message Text			<b>^</b>	- A	arm To Dev	vice
ZoneNotReady					Ev	vent Type	ZoneNotReady
ZoneReady					Me	essage lext	
ArmedStateOn							
ArmedStateOff							
AlarmStateOn							
AlarmStateOff							
PanicStateOn							
PanicStateOff							
LineCutStateOn							
LineCutStateOff				Ξ			
AcFailureStateOn							
AcFailureStateOff							
ArmFailureStateOn							
ArmFailureStateOff							
LowBatteryStateOn							
LowBatteryStateOff							
SecurityOff							
ArmedAway							
ArmedNight							
ArmedDay							
ArmedVacation							

This tab is used to link Comfort alarm events to Dynalite devices. For each event, a fixed text string can be sent when the event occurs, and another text string can be sent when the event is restored (off).

# **Commands to Device**

[emplate

List all the commands to be sent out to Dynalite devices. This is not normally used for Dynalite application. These commands (if any) will appear under the UCM >> Universal actions; in addition to UCM >> Dynalite actions.

TurnOnLvgAreaCh1: Turn On Living Area Ch 1						
$\bigcirc$ Oppend new action $\Rightarrow$ Insert new action $\bigcirc$ Delete action						
Action Source	e		Description			
Dynalite Line	arCA100ms Ucm02 1 (	0 1 0 255				
	Security					
	Keypad	- F				
	DoorStation	- F				
	Input	- F				
	Output					
	Counter	- <b>-</b>				
	Sensor	- <b>-</b>				
	Flag	- <b>-</b>				
	Do	- <b>-</b>				
	X10	- <b>-</b>				
	Schedule	- F 🗖				
	Test	- F 📙				
	Miscellaneous	- F				
	UCM	•	Dynalite			
	If		Universal			

## Write to EEPROM

When the Universal UCM configuration is completed, a WRITE to EEPROM is needed. Click the Write to EEPROM button shown below.

File Edit View	Transfer Opt	ions Tools	Help		
🗋 💕 🛃 🎒 🚨	1X B B 9	শি 🖉 🛛 📀	💿   🛔   🛃 🕕	🗐   👯   🛃 🔊   🎆	🔲   🛣 🚺
Comfort Modules		UCM02			
UCM's		💌 Write To EE	PROM 🛛 🔄 Read From	m EEPROM   Reset   Ge	et Status
UCM01		UCM/Universal F	Properties Device To C	omfort Alarm To Device	Commands
		UCM Prop	erties		
DoorStations		ld		2	
🔤 Slaves		Name		UCM02	
SCS & RIO's		Туре		Universal	
		Version		6.023	

## **Read From EEPROM**

Read from EEPROM reads the programmed information in the Universal UCM to Comfigurator.

## Reset

This button resets the EEPROM to factory default.

## **Get Status**

This reads the status of the Universal UCM to be displayed on the Status bar.

Refer to the Universal UCM Manual for details.

## Save Template / Load Template

The Universal UCM configuration that you have programmed can be saved as a template. Press the Save Template button to save as a .uutx file. The Load Template button loads the saved template into a new configuration file.

# Sending Commands to DyNet

The Response Wizard is used to send Commands to Dynalite Devices.

In Events > Responses, right click and select ADD RESPONSE. A Response is a small program in Comfort consisting of Actions which are commands in Comfort's programming language.



Enter a Description for the Response and press Enter. The Response name is automatically generated as shown

Ad	d New Respo	onse 🔀
	Response	Properties
	Number	19
1	Description	Living Area Ch 1 Preset 1
	Name	LivingAreaCh1Pr1
1		
ι.		
1.		
E		
N	ame	
Th	nis is a name w	which may be assigned to the Response to provide a meaningful description. You can see
W	nere a Respon	iser is referenced by right-clicking on the Name and selecting Show References. This will
	spiay a list of re	ererences identified by type and name.
		OK Cancel

Press OK. The new action screen appears. Select UCM > Dynalite (instead of Universal).

LivingAreaCh1Pr1: Living Area Ch 1 Preset 1							
🕴 🕥 Appe	○ Append new action ⇒ Insert new action ⊜ Delete action						
Action So	Security	•	1				
	Keypad	•					
	DoorStati	on 🕨					
	Input	•					
	Output	•					
	Counter	•					
	Sensor	•					
	Flag	•					
	Do	•					
	X10	•					
	Schedule	•					
	Test	•					
	Miscellan	eous 🕨	OK	٢			
	UCM	•	Dynalite				
	If		Universal				

The list of Dynalite commands is shown in the drop-down list

ivingAreaCh1Pr1: Living Area Ch 1 Preset	1						
📀 Append new action 🔿 Insert new action 🤤 Delete action 🛛 🕆 Move Up 👃 Move Down 🛛 🌱 Undo 陀 Redo							
Action Source	Description	Dynalite Action					
Dynalite Linear A100ms Llom02.0.0.1.0.255		Dynalite Action	Linear Channel/Area Control (100 msec units)				
Bynaite Encarcy round centre of ro 255		UCM Name	Linear Channel/Area Control (1 min units)				
		Area	Linear Channel/Area Control (1 sec units)				
		Join	Linear Channel/Area Control (100 msec units)				
		Channel	Linear Preset				
		Channel Level	Panel Disable				
		Fade Time	Panel Enable				
		Description	Panic				
			Preset Offset				
			Program to Current Preset				
			Ramp Channel/Area Down				
			Ramp Channel/Area Up				
			Recall Preset				
		Dynalite Action	Record Current Preset				
		The Dynalite action	Reset Preset				
			Stop Ramp Channel/Area				
	OF	Cancel	Un-Panic				

Select a command and the associated parameter and press OK.

Add more actions to the Response if required.

Several commands can be send to Dynalite in a single Response, for example

Dynalite LinearPreset Ucm02 1 0 0 255 Dynalite RampDownCA Ucm02 2 0 50 255 Dynalite LinearCA100ms Ucm02 3 0 1 0 255

### Write to Comfort

When the program is completed, write to Comfort. Go to Transfer > Write to Comfort. Also do not forget to Write to EEPROM in Universal UCM if you have not done so already.

### **Executing Responses**

Responses can be "executed" by clicking "Execute Response" on the right pane of the selected Response as shown below. This causes the Actions in the Response to be executed, and is a good way to test the Response.

Responses					
No	Name	Description		Response	Properties
No 1 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17	Name AutoDisamFromNi AutoAmNightFrom KEYARMDayModeFro KEYARMAwayFromSe KEYARMNightFromS BypassMenu HomeControlMenu TestMenu RecordMemoMenu EventLog ChangePhoneMenu ChangePhoneMenu ChangeCodeMenu AnsweringMachine EngineerCodeEnab UserCodesMenu ChangeTimeProgr0	Description         Auto Disam from Night Mode only and not in Alam         Auto Arm Night from Security Off only         KEY ARM Day Mode from Security Off         KEY ARM Away from Security Off         KEY ARM Night from Security Off or Day Mode         Bypass Menu         Home Control Menu         Test Menu         Event Log         Change Phone Menu         Change Code Menu         Answering Machine Menu         Engineer Code Enable. Activate Alam 30         User Codes Menu         Change Time Program	R	Response Fixed Description Name	Properties No 19 Living Area Ch 1 Preset 1 Living AreaCh1Pr1 Execute Response Urce Preset Ucm02 1 0 0 255
18 19	IntercomRequest LivingAreaCh1Pr1	Intercom Request Living Area Ch 1 Preset 1			

# **Comfort Events**

Responses can be triggered by Events in Comfort, eg Zone activated and Restored, Alarm Types, Time Programs, Home Control Menu, Doorbell, Phone ring, Sunrise/sunset times, System armed and disarmed and many more. For example the screen below Events > Miscellaneous Events, shows that Away Mode Response is assigned to AllLightsOff Response. This means that when the security system is armed to Away Mode, it will send a command to Dynalite to turn off the programmmed lights.

File Edit View Transfer	Options Tools Help						
🗋 💕 🛃 🎒 💁 🕹 🕷 🖻	୬ ୯   🕘   🕥 🔘   🐇   🛒 🄇	) 🗐   👬   🚟 🔊					
Comfort Modules Miscellaneous Events							
Configuration     Security     Security Type Settings     Telecoms     Control     Control     Control     Control     Control     Control     X10 Receive Codes     Signature     Room Responses     SCS/RIO Responses     SCS/RIO Responses     Counters     Miscellaneous Events     Sensor Responses     Sensor Responses     Sensor Responses     Sensor Responses     Schedule	Miscellaneous Responses     Security Off Response	NullResponse					
	Away Mode Response	AllLightsOff					
	Day Mode Response	NullResponse					
	Open Door Response Open Gate Response	NullResponse NullResponse					
	Doorbell Response Startup Response	NullResponse					
	Phone Ring Response	NullResponse					
	AL Restore Response Phone Trouble Restore Response	NullResponse					
	Start Arming Response Hourly Response	NullResponse NullResponse					
	Offhook Response	NullResponse					
i ⊕ i Mames	Sunrise Response	NullResponse					
	Sunset Response Door Station Voice On Response	NullResponse NullResponse					
	Door Station Voice Off Response	NullResponse					

# **Sample Configuration File**

A sample configuration file called Dynalite.cclx is available from the Cytech website.

# **Technical Notes: Action 197 for Dynalite Commands**

For an understanding of the concepts, please refer to the appropriate Dynalite documentation. It is beyond the scope of this manual to provide details of Dynalite operations.

Comfort interacts with Dynalite DyNet by sending DyNet commands to control the desired device on the network.

The Dynalite DyNet should be programmed beforehand. The list of logic addresses used should be known, i.e. The Area Number and Channel Number, for Comfort to integrate with Dynalite. Note that Comfort needs to be programmed separately.

Action 197 is used to send DyNet messages. The format of Action 197 is as follows:

### Format

197, ID, SyncByte, Byte1, Byte2, OpCode, Byte4, Byte5, Byte6, Checksum, 255

The parameters between the ID and terminator (255) are fixed as 8 bytes, which will determine the operation to be carried out.

### ID

This is the address of the UCM/Universal on the Comfort RS485 bus, i.e. 17 = UCM 1, 18 = UCM 2,...,24 = UCM 8. The UCM must correspond to the ID setting on SW7.

### SynchByte

SyncByte	Description
28	Logical Addressing Scheme
92	Physical Addressing Scheme

### OpCode

This determines the operation for which Dynalite is supposed to do, e.g. Ramping up, ramping down, etc. For the OpCode in greater details, please refer to the relevant Dynalite documentation.

### Some Commonly Used Commands

There are various commands that can be sent to DyNet to control Dynalite devices. The following are some commonly used commands:

### Linear Channel/Area Control

197, ID, SyncByte (0x1c), Area, Channel Number, OpCode (depends on Resolution), Channel Level, Fade, Join, Checksum, 255

### **Linear Preset**

197, ID, SyncByte (0x1c), Area, Preset, 0x65, Fade-low, Fade-high, Join, Checksum, 255

### Panel Disable/Enable

197, ID, SyncByte (0x1c), Area, 0x00, OpCode (depends on Disable/Enable), 0x00, 0x00, Join, Checksum, 255

### Panic/Un-Panic

197, ID, SyncByte (0x1c), Area, Fade-low, OpCode (depends on Panic/Un-Panic), Fade-high, 0x00, Join, Checksum, 255

### Preset Offset

197, ID, SyncByte (0x1c), Area, Offset, OpCode (0x64), 0x00, 0x00, Join, Checksum, 255

### **Program to Current Preset**

197, ID, SyncByte (0x1c), Area, 0x00, OpCode (0x08),0x00, 0x00, Join, Checksum, 255

### Ramp Channel/Area On/Off

197, ID, SyncByte (0x1c), Area, Channel Number, OpCode (depends on Target Level), 0x00, Ramping Rate, Join, Checksum, 255

### **Recall Preset**

197, ID, SyncByte (0x1c), Area, 0x00, OpCode (0x67), 0x00, Fade, Join, Checksum, 255

### **Record Current Preset**

197, ID, SyncByte (0x1c), Area, 0x00, OpCode (0x66), 0x00, 0x00, Join, Checksum, 255

### **Reset Preset**

197, ID, SyncByte (0x1c), Area, Fade-low, OpCode (0x0f), Fade-high, 0x00, Join, Checksum, 255

### **Stop Ramping**

197, ID, SyncByte (0x1c), Area, Channel Number, OpCode (0x76), 0x00, 0x00, Join, Checksum, 255

### Key Press / Key Release

197, ID, SyncByte (0x5c), Device Code of transmitting device, Box Number, OpCode (0x43), Button Number (0x01=button 1, 0x10=button 16), 0x00, Button state (0xff=Pressed, 0x00=Released), Checksum, 255

Document Title:DynaliteAppNote.lwpDate Last Modified:11 October 2012